

JANOME

OVERLOCKER SERIES



1200D Professional

1200D Professional

JANOME

1200D Features

20 pre-programmed stitches	Snap on presser feet	Tension release device
Cutting width 3.5mm to 7.5mm	Colour coded threading paths	Foot pressure adjustment dial
Blanket stitch	Easily accessible looper	Rolled hem changeover device
Stretch wrap stitch	Easy retractable upper-knife	Upper looper separation device
Automatic tension	Top cover stitch	Thread cutter on presser foot lifter
Stitch selection dial	Double chain stitch	Presser foot position sensor
Differential feed and stitch length dials	Rolled hem	Carrying handle
2, 3, 4 or 5 thread overlock	Cover stitch	Waste tray
28 optional feet and attachments incl. beading, pintuck, belt loop, etc.		Dust cover

Easy To See

The 1200D's clear blue plastic foot helps you view and sew your projects with ease.



Auto Upper Looper Deactivation

The 1200D upper looper system will automatically deactivate when top cover hem sewing is selected.

Top Cover Hem Device

This gives you the ability to sew a 5mm or a 2.5mm top cover hem as well as a bottom cover hem simultaneously. This allows you to produce a true industrial style cover hem.



Feet and Attachments

The 1200D gives you an array of specialty tools to take advantage of this machine's amazing abilities! With 28 optional feet and attachments, all of your sewing projects will get done quickly and easily. Create the look you want the way you want it with Janome's combined overlock and cover stitch machine accessory range.

2,3,4, or 5 Thread Convertible

A detailed threading chart is located right on the machine – so you'll always have threading instructions in front of you! Threading is made easy with colour coded thread paths, just follow the colour guide to thread.

20 Useful Stitches

With 20 pre-programmed stitches, the projects you can accomplish are virtually limitless. You'll find classic serger stitches, as well as advanced specialty stitches you'd normally find only on a professional machine.

Differential Feed and Stitch Length Dials

The differential feed and stitch length dials are located on the front of the machine for easy access, setting and reading. Janome engineering ensures seams on knits are wave and pucker-free.

Stitch Selection Panel

Simply select your sewing preference and the Janome 1200D thread tension system automatically adjusts the correct tension settings for you! This provides you comfort and confidence in knowing that you can attain perfect results with incredible ease.

JANOME

AVAILABLE FROM YOUR EXPERT JANOME RETAILER